

Banner Stands (Cobra)

1. Insert base crossbars in between base uprights and screw together (fig. 1).
2. Insert middle uprights into base uprights by aligning corresponding letters. Make sure push button faces towards the inside and clicks securely into place (fig. 2).
3. Insert top uprights into middle uprights by aligning corresponding letters. Make sure push button faces towards the inside and clicks securely into place (fig. 3).
4. Insert upright crossbars in between uprights and screw securely into place (fig. 4).
5. Slide graphic over frame like a pillowcase and zipper at bottom to close.

Applicable Products:

CBR

