

















CASTOR 10' X 10' KIT



Thank you for your purchase of Orbital Expo Truss Extreme. These instructions show how to erect the kit you purchased. The color coded section will help identify the location of each part.

 <p>6-WAY JUNCTION BOX 6</p>	 <p>45 CURVED TRUSS SECTION 0</p>	 <p>ADJUSTABLE SCALLOP TABLETOP 0</p>	 <p>INTERNAL SHELVES</p> <p>24" 0 36" 0 46" 0</p>
 <p>24\" TRUSS SECTION 4</p>	 <p>90 CURVED TRUSS SECTION 4</p>	 <p>50 WATT CHROME SPOTLIGHT 4</p>	 <p>ORBITAL FRATE CASE (OCF) 1</p>
 <p>36\" TRUSS SECTION 3</p>	 <p>UNIVERSAL CONNECTOR 0</p>	 <p>LONG CONNECTOR 80</p>	 <p>ORBITAL FRATE CASE (OCO) 0</p>
 <p>46\" TRUSS SECTION 3</p>	 <p>ADJUSTABLE TABLETOP 1</p>	 <p>SHORT CONNECTOR 28</p>	 <p>SCREW DRIVER 2</p>


Each Orbital Expo Truss Extreme kit has been carefully designed and developed to be stable and safe. Consult with your dealer for load bearing specifications. The manufacturers of Orbital Expo Truss Extreme will not be held responsible or accountable for damage or injury caused by exceeding guidelines or through wrongful/incorrect use of the system.



CASTOR 10' X 10' KIT



Color Coded Components



50 WATT CHROME
SPOTLIGHT

ADJUSTABLE
TABLETOP

6-WAY
JUNCTION BOX

24" LONG
TRUSS SECTION

36" LONG
TRUSS SECTION

46" LONG
TRUSS SECTION

CURVED TRUSS
SECTION



CASTOR 10' X 10' KIT



Color Coded Components

