

















HYDRUS 10' X 20' KIT



Thank you for your purchase of Orbital Expo Truss Extreme. These instructions show how to erect the kit you purchased. The color coded section will help identify the location of each part.

 <p>6-WAY JUNCTION BOX 12</p>	 <p>45 CURVED TRUSS SECTION 0</p>	 <p>ADJUSTABLE SCALLOP TABLETOP 0</p>	 <p>INTERNAL SHELVES</p> <p>24" 0 36" 0 46" 0</p>
 <p>24" LONG TRUSS SECTION 0</p>	 <p>90 CURVED TRUSS SECTION 10</p>	 <p>50 WATT CHROME SPOTLIGHT 5</p>	 <p>ORBITAL FRATE CASE (OCF) 1</p>
 <p>36" LONG TRUSS SECTION 6</p>	 <p>UNIVERSAL CONNECTOR 0</p>	 <p>LONG CONNECTOR 84</p>	 <p>ORBITAL FRATE CASE (OCO) 1</p>
 <p>46" LONG TRUSS SECTION 6</p>	 <p>ADJUSTABLE TABLETOP 2</p>	 <p>SHORT CONNECTOR 92</p>	 <p>SCREW DRIVER 3</p>

Each Orbital Expo Truss Extreme kit has been carefully designed and developed to be stable and safe. Consult with your dealer for load bearing specifications. The manufacturers of Orbital Expo Truss Extreme will not be held responsible or accountable for damage or injury caused by exceeding guidelines or through wrongful/incorrect use of the system.


ORBITAL

eXtreme
expo truss

HYDRUS 10' X 20' KIT



Color Coded Components



50 WATT CHROME
SPOTLIGHT



ADJUSTABLE
TABLETOP



6-WAY
JUNCTION BOX



24" LONG
TRUSS SECTION



36" LONG
TRUSS SECTION



46" LONG
TRUSS SECTION



CURVED TRUSS
SECTION



HYDRUS 10' X 20' KIT



Color Coded Components

