


















MARS 10' X 10' KIT




Thank you for your purchase of Orbital Expo Truss Extreme. These instructions show how to erect the kit you purchased. The color coded section will help identify the location of each part.

 <p>6-WAY JUNCTION BOX 13</p>	 <p>45 CURVED TRUSS SECTION 0</p>	 <p>ADJUSTABLE SCALLOP TABLETOP 0</p>	 <p>INTERNAL SHELVES</p> <p>24" 0 36" 0 46" 0</p>
 <p>24" LONG TRUSS SECTION 0</p>	 <p>90 CURVED TRUSS SECTION 0</p>	 <p>50 WATT CHROME SPOTLIGHT 2</p>	 <p>ORBITAL FRATE CASE (OCF) 1</p>
 <p>36" LONG TRUSS SECTION 5</p>	 <p>UNIVERSAL CONNECTOR 0</p>	 <p>LONG CONNECTOR 124</p>	 <p>ORBITAL FRATE CASE (OCO) 0</p>
 <p>46" LONG TRUSS SECTION 9</p>	 <p>ADJUSTABLE TABLETOP 2</p>	 <p>SHORT CONNECTOR 0</p>	 <p>SCREW DRIVER 2</p>


Each Orbital Expo Truss Extreme kit has been carefully designed and developed to be stable and safe. Consult with your dealer for load bearing specifications. The manufacturers of Orbital Expo Truss Extreme will not be held responsible or accountable for damage or injury caused by exceeding guidelines or through wrongful/incorrect use of the system.



MARS 10' X 10' KIT



Color Coded Components



50 WATT CHROME
SPOTLIGHT



ADJUSTABLE
TABLETOP



6-WAY
JUNCTION BOX



24" LONG
TRUSS SECTION



36" LONG
TRUSS SECTION



46" LONG
TRUSS SECTION




CURVED TRUSS
SECTION

ORBITAL

eXtreme
expo truss

MARS 10' X 10' KIT



Color Coded Components

