


















SATURN 10' X 20' KIT




Thank you for your purchase of Orbital Expo Truss Extreme. These instructions show how to erect the kit you purchased. The color coded section will help identify the location of each part.

 <p>6-WAY JUNCTION BOX 16</p>	 <p>45 CURVED TRUSS SECTION 0</p>	 <p>ADJUSTABLE SCALLOP TABLE TOP 0</p>	 <p>INTERNAL SHELVES</p> <p>24" 0 36" 0 46" 0</p>
 <p>24" LONG TRUSS SECTION 4</p>	 <p>90 CURVED TRUSS SECTION 0</p>	 <p>50 WATT CHROME SPOTLIGHT 5</p>	 <p>ORBITAL FRATE CASE (OCF) 2</p>
 <p>36" LONG TRUSS SECTION 16</p>	 <p>UNIVERSAL CONNECTOR 0</p>	 <p>LONG CONNECTOR 220</p>	 <p>ORBITAL FRATE CASE (OCO) 0</p>
 <p>46" LONG TRUSS SECTION 12</p>	 <p>ADJUSTABLE TABLE TOP 2</p>	 <p>SHORT CONNECTOR 0</p>	 <p>SCREW DRIVER 3</p>


Each Orbital Expo Truss Extreme kit has been carefully designed and developed to be stable and safe. Consult with your dealer for load bearing specifications. The manufacturers of Orbital Expo Truss Extreme will not be held responsible or accountable for damage or injury caused by exceeding guidelines or through wrongful/incorrect use of the system.



SATURN 10' X 20' KIT



Color Coded Components



50 WATT CHROME
SPOTLIGHT

ADJUSTABLE
TABLETOP

6-WAY
JUNCTION BOX

24" LONG
TRUSS SECTION


36" LONG
TRUSS SECTION

46" LONG
TRUSS SECTION

CURVED TRUSS
SECTION



SATURN 10' X 20' KIT



Color Coded Components

